





QUICK GUIDE

1





2




3


INSTALLATION: 1° PORTABLE / 2° FIX




4




5







6




7




OPENING




DEFAULT- AUTO MODE



MANUAL MODE




CUT IN default= 1.8 bar




ANTILEAKAGE (default disable)

ENABLE




ENABLE




CUT OUT (default disable)

ENABLE



DISABLE



ALARM

